



PIZZA WARMER INSTRUCTIONS



HATCO FLAV-R-FRESH HOLDING & DISPLAY CABINET

OPERATING INSTRUCTIONS

1. Turn 'on' power switch
2. Set humidity selector
3. Set temperature selector
4. Fill water reservoir
5. Load food into cabinet

TO FILL WATER RESERVOIR

Refill reservoir when red light is on (this restarts humidity cycle).
Fill through front opening until RED LIGHT GOES OFF.

CAUTION: Use distilled water only. Do not overfill.

MAINTENANCE:

Wipe clean daily. Use window cleaner on glass and a degreaser on metal parts.
On units with rotating racks, do not turn display rack manually.

CAUTION:

Empty reservoir before moving unit.
Use only 60W (max) coated light bulb when replacing display light.